



Model Number: IT414078

# INSTRUCTION MANUAL



## 6 Zone Wireless Alarm Kit

# Warranty Details



---

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

---

#### AFTER SALES SUPPORT

  1300 663 907

 [customercare@winplus.com.au](mailto:customercare@winplus.com.au)

MODEL: IT414078 PRODUCT CODE: 49098 02/2015



# Safety Instructions

Read this manual thoroughly before first use and keep it in a safe place for future reference, along with warranty card, purchase receipt and packaging. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to.

Follow all instructions and take notice of all warnings to reduce risk of fire or electric shock.

- Do not expose this product to water, rain, moisture or dust. Electronic products of this kind should never be subjected to moisture or extreme temperatures.
- There are no user-serviceable parts inside this product.
- Do not repair the unit yourself. If your device is not functioning correctly, disconnect the product from power, remove batteries, and contact after sales support.
- Supervise young children to ensure they do not play with the product.
- Do not expose to water, dust, moisture, chemicals, oils or other liquids.
- Do not expose to naked flames or other heat sources.
- Do not drop or subject the device to undue shock.
- Keep device away from magnets at all times.
- Keep away from direct sunlight.
- Unplug this device during lightning storms or when unused for long periods of time.
- Always observe basic security precautions – this device is not a substitute for basic security measures such as locking door and window locks.
- Keep batteries out of reach of children. Swallowing may lead to serious injury or death in as little as 2 hours due to internal burns. If swallowed, go straight to a hospital emergency room. Dispose of used batteries immediately.

# Contents

<b>Warranty Details</b>	<b>2</b>
<b>Safety Instructions</b>	<b>3</b>
<b>Parts List</b>	<b>5</b>
<b>Technical Specifications</b>	<b>5</b>
<b>Product Overview</b>	<b>6</b>
1.1 Product Features	6
1.2 Item Overview	6
1.3 Control Panel	7
1.4 PIR Sensor	7
1.5 Door/Window Sensor	8
1.6 Remote	8
<b>Installation</b>	<b>9</b>
2.1 Unpack	9
2.2 Control Panel Setup	9
2.3 PIR Sensor Setup	9
2.4 Door/Window Sensor Setup	10
2.5 Remote Control Setup	10
2.6 Arming The Alarm	10
2.7 Disabling The Alarm	10
2.8 Low Voltage Indicator	10
<b>Further Instructions</b>	<b>11</b>
3.1 Alarm Types	11
3.2 Code Pairing	11
3.3 Resetting Pairing	11
<b>Troubleshooting</b>	<b>12</b>
<b>Repair and Refurbished Goods or Parts Notice</b>	<b>13</b>

# Parts List

1 X Control Panel	3 x AA Batteries (Control Panel)
4 X Door/Window Sensors	6 x AAA Batteries (PIR Sensors)
2 x PIR Sensors	16 x LR44 Batteries (Door/Window Sensors)
2 x Key Ring Remote Controls	2 x CR2032 Batteries (Remotes)
1 x Getting Started Guide	2 x Mounting Accessories
1 x Instruction Manual	6 x Screws & Screw Anchor Sets
1 x Warranty Card	

# Technical Specifications

## Control Panel

Voltage:	4.5V DC (1.5V/AA *3) 5V USB Adapter
Frequency:	433.92MHz ± 250KHz
Distance:	65 m (Open Area)
Chime Mode:	- No delay when arming - Short alert tone
Alarm Mode:	- Alarm lasts 30 Seconds
Alarm Volume:	≈ 120dB

## Infrared Sensor

Power Supply:	4.5V DC (1.5V/AAA*3)
Infrared Sensing Distance:	≥ 6 m (Open Area)
Infrared Sensing Angle:	≥ 90°
Low Voltage Indicator:	< 3.3 V
Interval after Transmission:	≈ 5 Seconds
Frequency:	433.92MHz ± 250KHz
Transmission Distance:	60 M (Open Area)

## Remote Control

Battery Type:	CR2032
Frequency:	433.92MHz ± 250KHz
Transmission Distance:	≥ 60 M (Open Area)

## Door/Window Sensor

Voltage:	6V DC
Alarm Volume:	≈ 95dB
Frequency:	433.92MHz ± 250KHz
Response Distance:	≈ 15mm
Alarm Time:	≈ 10 Seconds
Transmission Distance:	50 m (Open Area)

## After Sales Support

 1300 663 907



customercare@winplus.com.au

Model Number IT414078


# Product Overview

## 1.1 Product Features

The Cocoon 6 Zone Wireless Alarm Kit is an all in one security solution designed for your home or small business. The Cocoon 6 Zone Wireless Alarm Kit will detect motion with PIR sensors and the door and window sensors will alarm if doors or windows are opened to ensure that your building is secure. When triggered, the 120dB siren will sound, deterring would be intruders. Simple DIY installation and complete battery operation allows you to set up sensors to suit your needs.

- 2 x Passive Infrared Sensors detect motion up to 8m away.
- 4 x Magnetic entry sensors to detect when a door or window has been opened.
- Wireless sensors for easy installation around your home or office.
- 120dB alarm to deter intruders when sensors are triggered.


## 1.2 Item Overview



- |                        |                        |
|------------------------|------------------------|
| 1. PIR Sensors         | 3. Remote              |
| 2. Alarm Control Panel | 4. Door/Window Sensors |

# Product Overview

## 1.3 Control Panel



- 1. Speaker
- 2. Indicator Lights
- 3. Mode Switch
- 4. Code Button
- 5. USB Port
- 6. Mounting Point
- 7. Battery Compartment

## 1.4 PIR Sensor



- 1. Infrared Sensor
- 2. Indicator Light
- 3. Mounting Point
- 4. Battery Compartment

### After Sales Support

1300 663 907




customercare@winplus.com.au

Model Number IT414078

# Product Overview

## 1.5 Door/Window Sensor



- 1. Sensor
- 2. Speaker

- 3. Indicator Light
- 4. Magnetic Strip

- 5. On/Off Switch
- 6. Battery Compartment

## 1.6 Remote



- 1. Lock Button
- 2. Unlock Button

- 3. Home Button
- 4. Emergency Button

### After Sales Support

1300 663 907



customercare@winplus.com.au

Model Number IT414078



# Installation

## 2.1 Unpack

Unpack the Cocoon 6 Zone Wireless Alarm Kit from the packaging and check you have all the components:

- 1 X Control Panel
- 4 X Door/Window Sensors
- 2 X PIR Sensors
- 2 X Key Ring Remotes
- 1 X Getting Started Guide
- 1 X Instruction Manual
- 2 X Mounting Accessories
- 6 x Screws & Screw Anchor Sets
- 1 X Warranty Card

- 2 x CR2032 Batteries
- 3 X AA Batteries
- 6 X AAA Batteries
- 16 X LR44 Batteries

Installed in control panel, sensors, and remote



## 2.2 Control Panel Setup

1. Remove back cover and remove plastic battery tabs to turn on device.

*Optional: Connect a Micro USB charger (Not Included) to power the unit*

2. Fix control panel to an interior wall by using the mounting accessories included.

*Note: To ensure that the distance between screws is correct, it is advised to first insert the ends of both screws into control panel, then gently press back of control panel against wall to create correctly spaced indents prior to screwing.*

## 2.3 PIR Sensor Setup

1. Remove PIR Sensor back cover and remove plastic battery tabs to turn on device.
2. Choose a location for each PIR sensor. An ideal location is one that an intruder is likely to walk past.
3. Determine installation height for each mounting bracket. It is recommended to install each sensor at least 1.5m above the ground.
4. Use 2 x screws to install mounting bracket at desired monitoring areas, then secure the PIR motion sensor to the bracket.
5. After installation, walk close to the sensor and watch for the LED indicator to flash. If the sensor flashes, then the sensor is working correctly.
6. Adjust the angle of the PIR sensor to achieve best detection coverage.

# Installation


## 2.4 Door/Window Sensor Setup


1. Remove Door & Window Sensor battery cover and remove plastic battery tab to engage device.
2. Choose a location for each Door/Window sensor.
3. Carefully remove the backing of the adhesive tape and attach transmitter and magnetic bar to a clean, dry surface on the opening edge of door or window. To ensure the best performance, align the transmitter and the magnetic bar, paying close attention that the distance between them is less than 12mm.
4. Turn the switch to the "ON" position, the internal alarm in the sensor will activate when the magnetic strip is moved away. When switched to the "OFF" position, the sensor will still activate, but the alarm will not sound, only the Control Panel will sound.
5. Close the battery cover.

## 2.5 Remote Control Setup


1. The remotes will come ready to use and don't require any setup.
2. Keep the remotes in a secure location that allows you to easily arm and disarm the alarm. An example is to attach the remote control to your keys or in a drawer beside your bed.

## 2.6 Arming The Alarm

**"Out" Arm Mode:** Press the  on the remote control to arm. The control panel will emit a warning tone. In this mode, the Door/Window sensors and PIR sensors can be triggered.

**"Home" Arm Mode:** Press the  on the remote control to arm. The control panel will emit a warning tone. In this mode, the Door/Window sensors can be triggered, however the PIR sensors cannot be triggered.

## 2.7 Disabling The Alarm

Press the  on the remote to turn off warning tone and exit arm mode.

## 2.8 Low Voltage Indicator

Each of the units will give an indication when their batteries need to be replaced.

**Control Panel:** When the status indicator lights start constantly flashing.


**Door & Window Sensors:** When the status indicator light starts constantly flashing.

**PIR Sensors:** When the status indicator light comes on constantly.

# Further Instructions

## 3.1 Alarm Types

The Cocoon 6 Zone Wireless Alarm Kit has different alarm modes to suit different needs:

**Emergency Mode:** If there is an emergency, press the  button on the remote control. The control panel will emit an alarm immediately.

**Alarm Mode:** The Control Panel will emit a loud alarm for 30 seconds after any of the sensors are activated.

**Chime Mode:** The Control Panel will emit a short tone when the PIR sensors are triggered signifying someone has entered a room. The Door/Window sensors will still emit an alarm sound when triggered.

## 3.2 Code Pairing

At times you may be required to re-pair a sensor, or pair a new sensor. Follow this procedure to ensure all sensors are paired correctly:

1. Press the CODE button on the side of the control panel. A warning tone (single beep) will indicate that pairing mode has begun.
2. The process for pairing the sensors and remotes vary:
  - a. Remote Controls: Press any key on the remote.
  - b. Door/Window Sensors: Trigger the sensor by simulating a door opening.
  - c. PIR Sensor: Activate the sensor by waving your hand in front of it.
3. If a pairing is successful, the alarm panel will flash a light and emit a tone (2 beeps).

*Note: The alarm panel will exit pairing mode automatically after 10 seconds of no use.*

## 3.3 Resetting Pairing

This procedure clears all previously paired sensors on the control panel, allowing all sensors to be paired individually again:

1. Ensure the Control Panel switch is set to "OFF".
2. Hold down the "CODE" button.
3. With the "CODE" button still held down, slide the switch to "ALARM" or "CHIME".
4. After 6 seconds the Control Panel will emit a warning tone, indicating the previously paired sensors have been cleared.
5. Release the "CODE" button.
6. To re-pair the sensors/remotes, follow the steps under section 3.2.

# Troubleshooting

Problem	Solution
The indicator light on my Control Panel is showing when an alarm is activated, however there is no sound.	<ul style="list-style-type: none"> <li>• Ensure that the batteries or optional USB adaptor are powering the unit correctly. Also ensure the switch on the side of the Control Panel is not set to OFF.</li> </ul>
I'm not able to receive an alarm signal from my Infrared Sensor.	<ul style="list-style-type: none"> <li>• Infrared sensors are only activated in 'OUT OF HOME' mode.</li> </ul>
My Control Panel cannot receive a signal from my remote control.	<ul style="list-style-type: none"> <li>• Perform CODE Pairing steps again.</li> </ul>
My Control Panel cannot receive the alarm signal from my door/window sensors.	<ul style="list-style-type: none"> <li>• Perform CODE Pairing steps again.</li> </ul>
There's no sound for my Door/Window sensor.	<ul style="list-style-type: none"> <li>• First ensure the switch on the Door/Window sensor is set to 'ON'. If there is still no sound from the sensor, perform CODE Pairing steps again.</li> </ul>
The PIR sensors are not registering movement.	<ul style="list-style-type: none"> <li>• Ensure the batteries in the units are charged - if not, try new batteries.</li> <li>• The PIR sensors work to detect movement from a still object, in rare cases, if an object is constantly moving, they may not detect further motion beyond the first time.</li> </ul>



## 6 Zone Wireless Alarm Kit

# Repair and Refurbished Goods or Parts Notice

---

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost.

**We recommend you save this data elsewhere prior to sending the product for repair.**

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

**Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.**

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 663 907 or write to us at:

Winplus Australasia  
PO BOX 537  
Bayswater Business Centre  
Bayswater, VIC 3153

Winplus Help Desk 1300 663 907  
(Operating Hours: Mon-Fri 08:30AM to 6:00PM)

customer@winplus.com.au  
www.winplus.com.au

---

#### AFTER SALES SUPPORT

 (AUS) 1300 663 907

 customer@winplus.com.au

MODEL: IT414078 PRODUCT CODE: 49098 02/2015







 cocoon™