



### GETTING STARTED GUIDE

## 1 UNPACK

Unpack the GPS unit, battery and USB cable from packaging.

1. Cocoon GPS Tracker Unit
2. Rechargeable battery
3. Charging Cable
4. Charging Adaptor
5. Weather Resistant Case



## 2 REMOVE BACK COVER



## 3 INSERT SIM CARD

Insert your Sim card (not supplied) ensuring SIM card contacts are aligned.



## 4 INSERT BATTERY

Insert supplied battery ensuring battery contacts are aligned.



## 5 REPLACE BACK COVER





## GPS TRACKER



### GETTING STARTED GUIDE

- 6** CHARGE THE GPS TRACKER  
Connect the USB cable to the GPS Tracker. Plug the other end into a USB port on your computer or included charger.

**NOTE:** Charge the GPS for a minimum of 4hrs before first use to maximize battery life.



- 7** HOLD DOWN POWER BUTTON  
Hold the power button for 5 secs then release. The unit is powered on when the GSM & GPS buttons are illuminated.



- 8** REGISTER YOUR MOBILE  
SMS **123456A1** to the phone number of the SIM card used in the Cocoon GPS tracker.

Your phone will then receive a SMS reply stating "1 Tel OK!" indicating you have set up correctly.

- 9** LOCATE THE TRACKER FROM YOUR MOBILE PHONE  
SMS the following code to the Cocoon GPS tracker : **123456F**  
The device will reply with a link to google maps showing the coordinates and location of the GPS Tracker.