



MY FIRST TABLET GETTING STARTED GUIDE

1 UNPACK FROM THE BOX
Power on by pressing the ON button.
Press the light button to turn on the light.



2 ANIMAL SOUNDS
Press the animal button to hear the sounds of each animal when you press them.



3 ANIMAL NAMES
Press the FACE button to hear the name of each animal when you press them.





4 VOLUME
You can alter the volume by using the volume buttons as shown.





MY FIRST TABLET GETTING STARTED GUIDE

5 SONGS

You can press the  icon to sing-a-long with Old MacDonald or the  icon to hear animal songs!



6 POWER OFF

When you're done playing, press the power button again to turn off the device.



CHANGING BATTERIES

My First Tablet comes with 3 x AA Activ Energy batteries.

To replace the batteries, simply unscrew the battery cover on the rear of the unit using a Phillips head screwdriver.

Remove the battery cover and replace the batteries, taking note of the polarity markings.

When the batteries are in place, reattach the battery compartment and ensure the screw is securely fastened.



Warning: Do not let children play with the battery cover or screw as these can present a choking hazard.

Years 3+

