



4 CAMERA HOME SECURITY SYSTEM WITH DVR



Getting Started Guide

HE180106
12/2018
Version 1.0

Note: We highly recommend reading the manual in full before testing and installing your home security system. Test all connections are working before permanently installing DVR and cameras. Position the DVR in a central location where all 4 cameras will reach. If you are wanting to use your DVR via mobile and/or PC, install near your router and refer to the user manual for further instructions on installation and operation.

- 1. Connect each of the camera BNC extension cables to the camera and power connectors, making note of the labeling on the extension cable.**



- 2. Connect the other end of the BNC extension cables to the video cable splitter. Connect the splitter to the port marked "VIDEO IN/OUT" on the side of the DVR.**



- 3. Connect the 4-way power splitter to each of the BNC extension cables.**





4 CAMERA HOME SECURITY SYSTEM WITH DVR



Getting Started Guide

HE180106
12/2018
Version 1.0

- 4. Connect the included HDMI cable to the back of the DVR and connect the other end of the HDMI cable to your monitor or TV.**

NOTE: You must switch your TV or monitor to the correct INPUT once the DVR has been powered on. For example, HDMI1

- 5. Connect the mouse to the rear USB port.**



- 6. Connect the power adaptor to the 4-way splitter and plug into an outlet. Switch the outlet on.**



- 7. Connect the remaining power adaptor to the DVR and plug into a mains outlet. Switch the outlet on. The DVR will begin the boot sequence.**

NOTE: Both the DVR and cameras operate "always on". To turn the cameras or DVR off, switch off the power adaptors at the power outlet

