



HE150112  
11/2015

## Getting Started Guide

### 1. UNPACK

Unpack the Retro Digital Radio from the packaging and check that you have received all components;


1x Retro Digital Radio  
1x Power Adaptor  
1x Instruction Manual

1x Getting Started Guide  
1x Warranty Card



### 2. CONNECT TO POWER

Insert the power adaptor into the rear of the radio and connect the other end to a power outlet. The Digital Radio will automatically set the time.



### 3. TURN ON

Press the POWER button to turn on the radio.

### 4. SELECT SOURCE

Press the SOURCE button to change between Digital, FM, AUX and Bluetooth modes.

### 5. SCAN FOR STATIONS

While in DAB+ or FM mode, press the SCAN button to scan for available stations.

### 6. TUNE IN A STATION

Turn the TUNE / SELECT dial to change between stations.

### 7. ENJOY

Congratulations, you have successfully setup your Digital Radio.

After you have finished using the Retro Digital Radio, press the POWER button again to return to standby mode.