

Using the phone holder with selfie light

HE180447
PLU: 700258
12/2019

1. Mounting your phone holder with selfie light

Using the clip at the end of the product, carefully clip the phone holder with selfie light to the edge of a table, desk or anywhere that the clip will grip securely

NOTE: You will need to check that you have access to either a computer or USB power adaptor and power supply for the selfie light

2. Mount your smartphone by securing it in the phone holder

Pull the top section of the phone holder to extend. Carefully place your phone between the top and bottom sections of the holder. Your phone should be firmly secured

NOTE: You won't need to remove your phone case

3. Lighting mode

Plug the USB into either a power adaptor (not supplied) or a computer/laptop (not supplied). Then press the power button on the control panel. On the control panel you can adjust the brightness of the LED selfie light by pressing the + to increase the brightness or the - to decrease the brightness. There are 10 levels for you to choose from. You can also change the colour of the white by pressing the ↻ button. There are three whites to choose from (these range from cold to warm white)

4. Position the phone holder with selfie light at your desired position and angle

Move the light around and the phone holder around until you are happy with the position of both of these. You can also adjust the angle of the phone holder

5. Once you are happy with the look, simply smile and start

Aim the mobile and press either the camera image to take a photo or start recording



*Smartphone not included



Using the phone holder with selfie light

HE180447
PLU: 700258
12/2019

Specifications

Input rating: 5V $\overline{=}$ 1A

Safety Instructions

- Do not look directly into the LEDs when operating
- LED light output is strong enough to injure human eyes. Precautions must be taken to prevent looking directly at the LEDs for more than a few seconds
- Long-life LED lights are not replaceable
- For indoor use only
- Keep away from liquids, oils, petrol, and all chemicals
- Do not exposure to heat sources
- Do not use if power supply cable becomes damaged or broken
- If the lighting fixture is damaged, it should be exclusively replaced by the manufacturer or the service agent or qualified person in order to avoid a hazard
- Never add any attachments and/or equipment without the approval of the manufacturer
- Unauthorized modifications may result in fire, electric shock or other personal injury and avoid your warranty
- Keep away from children
- Supervise young children to ensure they do not play with the product

After Sales Support

Phone: 1300 663 907

Email: help@cocoonproducts.com.au