

SMART SPOTLIGHT CAMERA

User guide

COCOON™

Model: HE210242
Version 1.2



Getting the most out of your Spotlight Camera:



Read the entire manual

It will help you set up with ease



Visit www.cocoonproducts.com.au

We have additional support videos and guides



Call After Sales Support - 1300 663 907

Or email help@cocoonproducts.com.au - we're always happy to help

If you experience any issues with this product or its performance is not what you had expected, please contact our friendly customer service team

It is likely that we can resolve problems for you via phone or email

We can be reached on:

Phone: 1300 663 907 (Mon - Fri; 8:30am - 6:00pm AEST)

Email: help@cocoonproducts.com.au

Web: www.cocoonproducts.com.au



COCOON™

SPOTLIGHT CAMERA

Warranty Details

**REGISTER YOUR PURCHASE AT www.aldi.com.au/en/about-aldi/product-registration/
TO KEEP UP-TO-DATE WITH IMPORTANT PRODUCT INFORMATION**

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

AFTER SALES SUPPORT

  1300 663 907

 help@cocoonproducts.com.au

MODEL: HE210242 PRODUCT CODE: 707034 10/2021



- Carefully read all safety instructions and the user manual before operation
- If power is reset then please allow 1-2 minutes for a Wi-Fi connection to be re-established
- Handle with care. Don't drop the Spotlight Camera, especially on a hard surface. Do not crush, squeeze, puncture, bend, deform, shred or submerge the Spotlight Camera in liquid
- Never use the Spotlight Camera if any part of it is damaged
- Do not attempt to open or disassemble the Spotlight Camera.
- Modifying any parts may void your warranty
- While the Spotlight Camera is rated IP65, do not expose it to strong water jets or submerge it. Avoid installing this product in a location with high humidity or in a location where liquid may consistently spill onto it. Liquid may cause a short circuit which can result in electric shock or fire. Never attempt to dry the Spotlight Camera with an appliance such as a hair dryer or in a microwave oven
- Do not wash the Spotlight Camera with corrosive or liquid aerosol cleaners. Always use a damp, soft cloth for cleaning
- Children should be supervised to ensure they do not play with this appliance. Close supervision is necessary when any appliance is used by or near children
- Do not install the Spotlight Camera near any heat sources such as radiators, stoves or other appliances that can generate heat
- At the end of its working life, observe local regulations when disposing of this product
- Dispose of batteries in an environmentally friendly manner
- The manufacturer is not responsible for loss or stolen goods
- Do not mix old and new batteries
- This unit comes supplied with Lithium Ion Batteries. Do not mix Alkaline, standard (Car-Zinc), or rechargeable (Nickel-Cadmium) batteries with this product. If the battery compartment does not close securely, stop using the product and keep it away from children
- Batteries should not be exposed to excessive heat such as sunshine, fire or the like
- The battery should be charged at least every three months to avoid shortening the battery life
- Dispose of used batteries according to the instructions
- **CAUTION: Risk of explosion**
- If the battery is replaced by an incorrect type.
- If the battery is subjected to high or low extreme temperatures that a battery can be subjected to during use, storage or transportation.
- If the battery is subjected to low air pressure at high altitude.
- Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types).
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- NOTE: Recommended installation height is 2m maximum.

This product has been tested to AS/NZS CISPR 32, AS/NZS 4268 and AS/NZS 62368.1.

After Sales Support

☎ 1300 663 907

help@cocoonproducts.com.au
www.cocoonproducts.com.au

Model number: HE210242
10/2021

Warranty Note	3
Safety Instructions	5
Contents	6
Parts List	7
Technical Specifications	7
Installing the Cocoon Connect App	8
Before you start	8
Setting up the Cocoon Connect application for the first time	8
Create a Home	9
Setup	10
Charging the batteries	10
Setting up the Spotlight Camera in the Cocoon Connect app	10
Operation	12
Main controls	12
Settings menu	13
Additional Functionality	14
Adding other Cocoon Connect accounts to your Home	14
MicroSD card usage	14
Troubleshooting	15
Firmware updates	15
FAQs	16
Maintenance, Storage & Disposal	17

1. 1 x Spotlight Camera
2. 1 x Magnetic mount
3. 1 x Screw for magnetic mount*
4. 1 x USB charging cable*
5. 1 x Getting started guide*
6. 1 x User guide*
7. 1 x Warranty certificate*

*Not shown



Technical Specifications

- 1080P Resolution
- Water resistant IP65
- Wide angle lens
- Micro SD Slot (up to 128GB, card not included)
- Rechargeable batteries via USB
- Wi-Fi 2.4Ghz
- Night vision
- 2 way audio
- DC Power Input: 5V d.c. 1A
- Battery rating: 3.6V d.c. 2500mAh X 2

NOTE:

- *Your phone does not have to be connected to your local Wi-Fi to use this device, however mobile charges may apply*
- *The Cocoon Connect App is subject to change over time. The manual is written as per Cocoon Connect app version 1.1.6. Please see our website for any updates on the app*

Before you start



- Know your Wi-Fi network & password
- The Spotlight Camera requires a Wi-Fi connection to communicate to the Cocoon Connect application
- Make sure your mobile device is running iOS 10 or higher or Android 4.4 or higher

**Setting up the Cocoon Connect application for the first time**

1. Download the Cocoon Connect application by scanning the QR code provided or downloading it from the iOS App Store or Google Play Store
2. Launch the application and select Register to register a Cocoon Connect account
3. Select Agree to Terms and Conditions and then you will be required to enter an email address and press Obtain verification code. A verification code will then be sent to the email address you entered
4. Enter the verification code into the password field
5. Set the password for your Cocoon Connect account



OPTIONAL: Click on eye icon to unhide the password



Create a Home



The first time you set up the Cocoon Connect application, you will be prompted to create a Home.

Creating a home allows you to invite other Cocoon Connect account holders to control the same device. Creating a home is a good way of giving other household members control of Connected Home devices

1. Select Create home
2. Enter a name for the Home, for example use your surname, address or workplace etc.
3. Set the location for the Home. If location is turned on, the Cocoon Connect application can use your smartphone's GPS function to pinpoint your location.

NOTE: You do not have to enter a location or use this feature



4. Select (or un-select) rooms which will have Cocoon Connect devices (e.g. living room, bedroom, front door). Add new rooms if required
5. Select Done on the top right-hand side to create the Home. You will get the confirmation Home Created Successfully




Charging the batteries

1. Plug the Micro USB end of the USB cable into the bottom of the Spotlight camera
2. Plug the other end of the USB cable into a DC 5V USB power supply (Not included)

Setting up the Spotlight Camera in the Cocoon Connect app


1. Open the Cocoon Connect app on your phone which is connected to your Wi-Fi network and log into your account
2. Select the  Home tab on the bottom left hand side
3. Select the  icon on the top right-hand side or select Add Device to add a product
4. Select Add Manually, select AU in the menu on the left hand side, then select the Spotlight Camera icon on the right



5. Turn on the camera via the power button underneath the silicone cover at the bottom of the spotlight camera
6. Confirm the red LED on the Spotlight Camera is flashing by selecting Next Step. If not, reset the camera as per “FAQs” on page 16
7. Verify that your smartphone is connected to the Wi-Fi network you wish to connect the Spotlight Camera to.
 - a. With initial connection, it is recommended to have the Spotlight Camera near your Wi-Fi router to ensure a clear network connection
 - b. If there is more than one Wi-Fi network, you can change the Wi-Fi network your phone is connected to by selecting the Wi-Fi network name. You will be taken to your settings where you can change your network settings. Once changed, return to previous screen to enter your Wi-Fi password
 - c. Enter your local Wi-Fi password and select Confirm. You can click on the eye icon to see your password on your screen

Setup


8. With the local Wi-Fi network confirmed, you will need to scan a unique QR Code that will appear on your phone
 - a. Tap Continue and a QR Code will be displayed on the phone screen
 - b. Place the phone approximately 15-20cm in front of the Spotlight Camera (LED blinking rapidly) with the QR code facing the camera
 - c. The Spotlight Camera will read the unique QR code and an audible sound will be heard
 - d. Once you hear the sound, select Heard the Beep on the application
 - e. If you do not hear a beep, select Heard nothing at all on the app and follow instructions on screen (see “Troubleshooting” on page 15)
9. Having selected Heard the Beep the application will begin registering the device with your account. This can take a few minutes
10. Once the Spotlight Camera is paired with the app, you will be asked to name it and to select a room
 - a. The name of the Spotlight Camera should be simple and descriptive
 - b. Select the room icon to select the Spotlight Camera’s location
 - c. Then select Complete. The app will then start retrieving the camera’s video stream
11. You can also view the video stream from the Product Control Screen
 - a. Your phone does not have to be connected to your local Wi-Fi to view the Spotlight Camera (however mobile data charges may apply if it’s not)



Main controls


Once added to the Cocoon Connect app, you can tap on the Spotlight Camera from the home screen to access the video feed and controls. Each of the items on the screen allow the following functions:

- HD / SD:** High Definition or Standard Definition selection
- Battery:** Shows the cameras current battery percentage
- Speaker:** Select to hear audio from the camera
- Fill screen & Zoom:** You can pan and zoom to focus in on the high-def details of any live video. Just pinch and drag to zoom in on a particular area
- Settings:** Allows you to adjust further settings for the camera (see below)
- Date & Time Watermark:** Displays the device's date and time on video stream (must be turned on in settings)
- Full Screen Icon:** Plays the video in full screen
- Screenshot:** Takes a screenshot of the current video stream onto your smartphone
- Speak:** Hold this button to allow two-way communication. Unmutes camera
- Record:** Activates the recording of real time video onto your Smartphone
- Show options:** Show or hide additional options on this screen
- Playback:** Allows the playback of video stored on the SD Card (sold separately) in the Spotlight Camera
- Gallery:** Shows all images or video recorded using app on local device
- Theme colour:** Toggle between light and dark mode
- Device volume:** Adjust the volume on your device from 1-10
- PIR:** Adjust motion sensitivity between Off, Low, Medium or High
- Siren:** Trigger the siren and it's powerful sound
- Light:** The Camera has its own built-in smart lighting system to light up your path at night. Manually turn on. It has to be dark in order for this function to work. You can control the brightness of the light via this button. You can use from 1%-100%
- Messages:** Shows list of notifications from this camera
- Features:** Toggle to show features on this screen



Settings menu

- a. **Device Name:** Allows user to edit the name and Room location of the Spotlight Camera
- b. **Device Information:** Provides the device owner account name, device's IP address, the unique device ID, device time zone & the Wi-Fi strength of the network
- c. **Tap-to-run and automation:**
- d. **Third party support:**
- e. **Basic Function Settings:**
 - Flip Screen: Rotates the video stream 180°
- f. **Sounds:** Adjust the volume on your device from 1-10
- g. **Detection alarm settings:**
 - Activity area: An activity area focuses motion detection on a specific area within your camera's field of view
 - Human body filtering: When the human body filtering is activated, the camera will only detect human body motions. If it is deactivated, the camera detects all kinds of motions including animals, cars, etc
- h. **Motion Detection:** Adjust motion sensitivity between Off, Low, Medium or High
- i. **Power Management Settings:** Displays battery remaining, power source and set low battery threshold
- j. **Storage Settings:**
 - Storage Capacity: Shows total, used and remaining capacity of SD Card (SD Card not included)
- k. **Offline notification:** To avoid constant reminders, a notification will be sent if the device stays offline for over 30 minutes
- l. **FAQ & Feedback:** The user can access our FAQs and also provide feedback via the app to resolve networking, application and device issues
- m. **Share Device:** Allows user to share device to another user.
It is recommended to share device via home management option (see "Adding other Cocomoon Connect accounts to your Home" on page 14) so a Home member can control the device
- n. **Add to home screen:** Adds an icon to your phone's home screen linking directly to this camera
- o. **Firmware information:** Provides current firmware version of the application, the last time it was updated and allows the user to check for firmware upgrades
- p. **Remove Device:** Allows you to remove the Spotlight Camera from your account and home



Now that you have set up this device you may want to connect it with other Cocoon Connect devices. For example, you may want a Smart Bulb to activate if a motion is detected. Instructions for applying such functions can be found on our website <https://cocoonproducts.com.au/>

Voice control, via third party support, is also another great way to control Cocoon Connect products. Voice control instruction can be found in our manual online. In addition, you will find a list of associated commands.

Adding other Cocoon Connect accounts to your Home

Follow these steps to add allow other Cocoon Connect accounts access to a Home:

1. Select your current Home in the top left corner of the main page and select Home Management
2. Select the Home you want to allow another account to access
3. Select Add Member - the home member must set up an account prior to adding them
4. Fill out the details for the new Home member
5. Select if you want to give that account administrator rights - allowing them to make changes to the settings of devices in that home (including removing the whole home). This will also allow them to create automations of these devices
6. Select completed and Cocoon Connect will send an invitation for the account to join the home to access the connect devices

MicroSD card usage

The Spotlight Camera can be used with a MicroSD card (not included) to record and store footage to review later. The MicroSD card slot can be found under the silicone tab on the base of the camera.

My connection process does not work

If your connection process fails, then you may see the screen to the right

Failed to add device

There are several potential problems, including but not limited to an incorrect Wi-Fi password, router firewall settings, network firewall settings, poor wireless communication and security settings on router. With the initial connection, it is recommended to have the device near your Wi-Fi router to ensure a clear network connection. For further troubleshooting, press the View Details tab

Why is there no prompt from the camera?

If the device is not providing a prompt when the QR code is help up to the camera lens try the below:

1. Ensure that the lens is not blocked. If the camera has a protective film, remove it before you scan the QR code
2. Place the app QR code in front of the camera at a distance of 15cm to 20cm. Adjust the angle and distance until you hear a prompt
3. Reset your camera and try step 2 again

Firmware updates

Visit <https://support.cocoonproducts.com.au> for the latest firmware updates for the Spotlight Camera

Warning: Before installing any firmware updates the camera must have at least 80% battery charge. It is recommended that you recharge your Spotlight Camera completely before any firmware update. If there is not enough battery power there is a risk the firmware will not load correctly, rendering the camera unusable. Do not power off the camera during a firmware update.



Question	Solution
I can't get the LED to blink rapidly for set up of my Spotlight Camera	Ensure that the camera is powered up and hold the Reset button down for 6 seconds. The Spotlight Camera's red LED will start blinking rapidly
My Spotlight Camera does not load on my App	Check that your internet router is on and reset if needed. Please see the troubleshooting section for when the connection process does not work.
What if my Router is not 2.4GHz?	Wi-Fi routers operate in two bands, 2.4GHz and 5GHz. Some routers operate on both bands simultaneously. The Cocoon Spotlight Camera can only operate on the 2.4GHz frequency.
Why are the speaker and microphone not working?	Check the app settings to make sure they are not disabled
How do I turn On/Off Push Notifications?	Push notifications for the camera can be accessed in the settings function under motion detection. Push notifications for your whole account can be accessed via the settings in the 'Me' menu
Where can I get additional Cocoon Connect products?	Additional Cocoon Connect smart home products are available at your local ALDI store and at https://cocoonproducts.com.au

For more information, setup guides and videos, please visit

<https://cocoonproducts.com.au>

The Spotlight Camera does not require scheduled maintenance or cleaning. Should cleaning be necessary, simply wipe the outside surface with a dry soft cloth. Be sure to unplug this device before cleaning.

Always store your device in a clean dry environment and avoid storage in extreme heat or cold.

At the end of its working life, do not throw this product out with your household rubbish. Electrical and electronic products contain substances that can have a detrimental effect on the environment and human health if disposed of inappropriately. Observe any local regulations regarding the disposal of electrical consumer goods and dispose of it appropriately for recycling. Contact your local authorities for advice on recycling facilities in your area.

Observe and local regulations regarding the disposal of waste products. Contact your local authorities for advise on recycling facilities in your area.

Please keep the original packaging carton and materials in a safe place. It will help to prevent any damage if the product needs to be transported in the future. In the event it is to be disposed of, please recycle all packaging material where possible.

If you require another copy of this instruction manual, please contact help@cocoonproducts.com.au to obtain an electronic copy.



COCOON™

SPOTLIGHT CAMERA

Repair and Refurbished Goods or Parts Notice

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost.

We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 663 907 or write to us at:

Balco Brands Pty Ltd
PO Box 537 Bayswater Business Centre, Victoria, Australia
1300 663 907 - Hours: Mon-Fri 8:30am - 6:00pm AEST
help@cocoonproducts.com.au

AFTER SALES SUPPORT

 1300 663 907

 help@cocoonproducts.com.au

MODEL: HEZ10242 PRODUCT CODE: 707034 10/2021



COCOON™

After Sales Support

Ph. 1300 663 907
help@cocoonproducts.com.au